

COMPATIBILITY

	Not Refillable
	Separate Instructions
	Checking For Updates
	NEW
	Cannot Refill Originals
	Ammendments

Printer Type	Printer Series	Model No	Page No
Apollo	~	P-1200	1 & 2
Apollo	~	P-1200i	1 & 2
Apollo	~	P-1220	1 & 2
Apollo	~	P-1250	1 & 2
Apollo	~	P-1250i	1 & 2
Apollo	~	P-2000	1 & 2
Apollo	~	P-2100	1 & 2
Apollo	~	P-2100u	1 & 2
Apollo	~	P-2150u	1 & 2
Apollo	~	P-2200	1 & 2
Apollo	~	P-2250	1 & 2
Apollo	~	P-2500p	1 & 2
Apollo	~	P-2500u	1 & 2
Apollo	~	P-2550	1 & 2
Apollo	~	P-2600p	1 & 2
Apollo	~	P-2600u	1 & 2
Apollo	~	P-2650	1 & 2

	Not Refillable
	Separate Instructions
	Checking For Updates
	NEW
	Cannot Refill Originals
	Ammendments

Printer Type	Series Type	Model No	Page No
Apple	~	Deskwriter	1
Apple	Colour Stylewriter	4100	1 & 2
Apple	Colour Printer/ColourJet	~	8
Apple	Colour Stylewriter Pro	~	8
Apple	Colour Stylewriter	~	8
Apple	Colour Stylewriter	Portable	9
Apple	Stylewriter	~	9
Apple	Stylewriter	1200	9
Apple	Colour Stylewriter	1500	9
Apple	Colour Stylewriter	2500	9
Apple	Stylewriter	I	9
Apple	Stylewriter	II	9
Apple	Stylewriter	2400	10
Apple	Colour Stylewriter	2410	10
Apple	Stylewriter	2200	11
Apple	Colour Stylewriter	4500	15 &16
Apple	Colour Stylewriter	4500 Photo	15 &16
Apple	Colour Stylewriter	6500	15 &16

	Not Refillable
	Separate Instructions
	Checking For Updates
	NEW
	Cannot Refill Originals
	Ammendments

Brother	Inkjet Printer	DP-80	12
Brother	Inkjet Printer	DP-530cj	12
Brother	Inkjet Printer	DP-530cj mail	12
Brother	Inkjet Printer	DP-540cj	12
Brother	Inkjet Printer	DP-540cj mail	12
Brother	Inkjet Printer	DP-550cj	12
Brother	Inkjet Printer	DP-5040cj	12
Brother	Inkjet Printer	DP-300cj	12
Brother	Inkjet Printer	DP-350cj	12
Brother	Inkjet Printer	GW-70i	9
Brother	Inkjet Printer	GW-80i	9
Brother	Inkjet Printer	HJ-100	9
Brother	Inkjet Printer	HJ-100i	9
Brother	Inkjet Printer	HJ-400	9
Brother	Inkjet Printer	HJ-770	8
Brother	Intellifax	1820c	19
Brother	Intellifax	1800c	19
Brother	Intellifax	1920cn	19
Brother	Inkjet Printer	LW-700i	12
Brother	Inkjet Printer	LW-710i	12
Brother	Inkjet Printer	LW-730i	12
Brother	Inkjet Printer	LW-750i	12
Brother	Inkjet Printer	LW-800ic	12
Brother	Inkjet Printer	LW-830ic	12
Brother	Inkjet Printer	LW-840ic	12
Brother	Inkjet Printer	MC-3000	23
Brother	Multi Function Center	MFC-580	19
Brother	Multi Function Center	MFC-590	19
Brother	Multi Function Center	MFC-700c Pro	23
Brother	Multi Function Center	MFC-730	19
Brother	Multi Function Center	MFC-740	19
Brother	Multi Function Center	MFC-760	19
Brother	Multi Function Center	MFC-890	19
Brother	Multi Function Center	MFC-3100	19

Brother	Multi Function Center	MFC-3200c	19
Brother	Multi Function Center	MFC-3200j	19
Brother	Multi Function Center	MFC- 3220	19
Brother	Multi Function Center	MFC-3220c	19
Brother	Multi Function Center	MFC-3220cn	19
Brother	Multi Function Center	MFC-3320cn	19
Brother	Multi Function Center	MFC-3420c	19
Brother	Multi Function Center	MFC-3820c	19
Brother	Multi Function Center	MFC-3820cn	19
Brother	Multi Function Center	MFC-5100c	19
Brother	Multi Function Center	MFC-5100j	19
Brother	Multi Function Center	MFC-5200c	19
Brother	Multi Function Center	MFC-5200j	19
Brother	Multi Function Center	MFC-7000	23
Brother	Multi Function Center	MFC-7000c	23
Brother	Multi Function Center	MFC-7050c	12
Brother	Multi Function Center	MFC-7100	19
Brother	Multi Function Center	MFC-7150	19
Brother	Multi Function Center	MFC-7150c	19
Brother	Multi Function Center	MFC-7160c	19
Brother	Multi Function Center	MFC-7200c	23
Brother	Multi Function Center	MFC-7200fc	23
Brother	Multi Function Center	MFC-7300	19
Brother	Multi Function Center	MFC-7300c	19
Brother	Multi Function Center	MFC-7400	19
Brother	Multi Function Center	MFC-9100c	19
Brother	Multi Function Center	MFC-9200	19
Brother	Multi Function Center	MFC-9200c	19
Brother	Multi Function Center	MFC-9300	19
Brother	Multi Function Center	MFC-9300c	19
Brother	Multi Function Center	MFC-9100	19
Brother	PRIVILEG	200i	9
Brother	PRIVILEG	2000i	9
Brother	PRIVILEG	2001i	12
Brother	ENSEMBLE	PDP	12
Brother	ENSEMBLE	PDP-100j	12
Brother	ENSEMBLE	PDP-300cj	12
Brother	ENSEMBLE	PDP 300	12
Brother	ENSEMBLE	PDP-350cj	12
Brother	Inkjet Printer	HC-2500	23
Brother	WHISPERWRITER	II	9
Brother	WHISPERWRITER	WP-6400j	12
Brother	WHISPERWRITER	WP-6500j	12
Brother	WHISPERWRITER	WP-6550j	12

Brother	WHISPERWRITER	WP-6700j	12
Brother	Inkjet Printer	DP-525cj	12
Brother	Intellifax	1920	19
Brother	Inkjet Printer	LDC-1117	9
Brother	Inkjet Printer	LW-810	12
Brother	Multi Function Center	MFC-420cn	~
Brother	Multi Function Center	MFC-700	23
Brother	Multi Function Center	MFC-830	19
Brother	Multi Function Center	MFC-840	19
Brother	Multi Function Center	MFC-860	19
Brother	Multi Function Center	MFC-1820c	19
Brother	Multi Function Center	MFC-7400c	19
Brother	WHISPERWRITER	WP-6700cj	12
Brother	WHISPERWRITER	WP-7000	9
Brother	WHISPERWRITER	WP-7000j	9
Brother	WHISPERWRITER	WP-7400j	12
Brother	WHISPERWRITER	WP-7500j	9
Brother	WHISPERWRITER	WP-7550j	12
Brother	WHISPERWRITER	WP-7550j+	12
Brother	WHISPERWRITER	WP-7550jspl	12
Brother	WHISPERWRITER	WP-7700cj	12
Brother	WHISPERWRITER	WP-7800j	9
Brother	WHISPERWRITER	WP-7800cj	9
Brother	Inkjet Printer	CW-1000	~
Brother	Inkjet Printer	DCP-110c	~
Brother	Inkjet Printer	DCP-310cn	~
Brother	Intellifax	1835c	~
Brother	Intellifax	1840c	~
Brother	Intellifax	1940cn	~
Brother	Intellifax	2440c	~
Brother	Multi Function Center	MFC-110c	~
Brother	Multi Function Center	MFC-210c	~
Brother	Multi Function Center	MFC-410cn	~
Brother	Multi Function Center	MFC-620cn	~
Brother	Multi Function Center	MFC-3240c	~
Brother	Multi Function Center	MFC-3340cn	~
Brother	Multi Function Center	MFC-5440cn	~
Brother	Multi Function Center	MFC-5840cn	~
Brother	Multi Function Center	DCP-115c	~
Brother	Multi Function Center	DCP-120c	~
Brother	Multi Function Center	DCP315cn	~
Brother	Multi Function Center	MFC-215c	~
Brother	Multi Function Center	MFC-425c	~
Brother	Multi Function Center	MFC-620c	~

Brother	Multi Function Center	DCP-117c	~
Brother	Inkjet Printer	HS-5300	?
Brother	Inkjet Printer	MP-21c	?
Brother	Inkjet Printer	MP-21cdx	?
Brother	Multi Function Center	MFC-4020c	N/R
Brother	Multi Function Center	MFC-4220	N/R
Brother	Multi Function Center	MFC-4420c	N/R
Brother	Multi Function Center	MFC-4820c	N/R
Brother	Multi Function Center	MFC-9000	N/R
Brother	Multi Function Center	MFC-100	N/R
Brother	Multi Function Center	MFC-150cl	N/R
Brother	Multi Function Center	MFC-150clw	N/R
Brother	Fax	1815c	19
Brother	Multi Function Center	MFC-9000	~

	Not Refillable
	Separate Instructions
	Checking For Updates
	NEW
	Cannot Refill Originals
	Ammendments

Printer Type	Series Type	Printer No	Page No
BT	Fax DF	450	17
BT	Image	2000	12
BT	Image	2001	12
BT	Paperjet	50	17
BT	Paperjet	50E	12
BT	Paperjet	55	17
BT	Paperjet	55E	12
BT	Paperjet	60	17
BT	Paperjet	60E	12
BT	Paperjet	65	17
BT	Paperjet	65E	12
BT	Paperjet	150	12
BT	Multijet	3000	12
BT	Fax	BF-550	17
BT	Fax	BF-555	17
BT	Fax	PPJ65C	17
BT	Paperjet	100	N/R
BT	Paperjet	200	N/R
BT	Paperjet	35	23

	Not Refillable
	Separate Instructions
	Checking For Updates
	NEW
	Cannot Refill Originals
	Ammendments

Printer Type	Series Type	Model No	Page No
Canon	Bubblejet	BCJ-411f	10
Canon	Bubblejet	BCJC-455j	10
Canon	Bubblejet	BJ -Note	11
Canon	Bubblejet	BJ-10	9
Canon	Bubblejet	BJ-100	9
Canon	Bubblejet	BJ-10e	9
Canon	Bubblejet	BJ-10ex	9
Canon	Bubblejet	BJ-10sx	9
Canon	Bubblejet	BJ-10v	9
Canon	Bubblejet	BJ-130	8
Canon	Bubblejet	BJ-130E	8
Canon	Bubblejet	BJ-15v	9
Canon	Bubblejet	BJ-20	9
Canon	Bubblejet	BJ-200	9
Canon	Bubblejet	BJ-200e	9
Canon	Bubblejet	BJ-200ex	9
Canon	Bubblejet	BJ-200jc	9
Canon	Bubblejet	BJ-20ex	9
Canon	Bubblejet	BJ-220js	9
Canon	Bubblejet	BJ-230	9
Canon	Bubblejet	BJ-30	11
Canon	Bubblejet	BJ-300	8
Canon	Bubblejet	BJ-300j	8
Canon	Bubblejet	BJ-30e	11
Canon	Bubblejet	BJ-30v	11

Canon	Bubblejet	BJ-330	8
Canon	Bubblejet	BJ-330j	8
Canon	Bubblejet	BJ-360	9
Canon	Bubblejet	BJ-5	9
Canon	Bubblejet	BJC-10	9
Canon	Bubblejet	BJC-1000	9
Canon	Bubblejet	BJC-1010	9
Canon	Bubblejet	BJC-130	9
Canon	Bubblejet	BJC-150	9
Canon	Bubblejet	BJC-20	9
Canon	Bubblejet	BJC-200	9
Canon	Bubblejet	BJC-200+	9
Canon	Bubblejet	BJC-2000	10
Canon	Bubblejet	BJC-200ex	9
Canon	Bubblejet	BJC-200s	9
Canon	Bubblejet	BJC-2010	10
Canon	Bubblejet	BJC-210	9
Canon	Bubblejet	BJC-2100	10
Canon	Bubblejet	BJC-210j	9
Canon	Bubblejet	BJC-2110	10
Canon	Bubblejet	BJC-2115	10
Canon	Bubblejet	BJC-2120	10
Canon	Bubblejet	BJC-2125	10
Canon	Bubblejet	BJC-2130	10
Canon	Bubblejet	BJC-220	9
Canon	Bubblejet	BJC-220jc	9
Canon	Bubblejet	BJC-220jcii	9
Canon	Bubblejet	BJC-220js	9
Canon	Bubblejet	BJC-230	9
Canon	Bubblejet	BJC-232	10
Canon	Bubblejet	BJC-240	9
Canon	Bubblejet	BJC-240i	9
Canon	Bubblejet	BJC-240j	9
Canon	Bubblejet	BJC-240jp	9
Canon	Bubblejet	BJC-250	9
Canon	Bubblejet	BJC-250j	9
Canon	Bubblejet	BJC-250jp	9
Canon	Bubblejet	BJC-250p	9
Canon	Bubblejet	BJC-251	9
Canon	Bubblejet	BJC-255	9
Canon	Bubblejet	BJC-3000	22
Canon	Bubblejet	BJC-300j	8
Canon	Bubblejet	BJC-3010	22
Canon	Bubblejet	BJC-3100	22

Canon	Bubblejet	BJC-323	10
Canon	Bubblejet	BJC-330j	8
Canon	Bubblejet	BJC-35	11
Canon	Bubblejet	BJC-35v	11
Canon	Bubblejet	BJC-35vii	11
Canon	Bubblejet	BJC-400	10
Canon	Bubblejet	BJC-4000	10
Canon	Bubblejet	BJC-400j	10
Canon	Bubblejet	BJC-410	10
Canon	Bubblejet	BJC-4100	10
Canon	Bubblejet	BJC-410j	10
Canon	Bubblejet	BJC-4200	10
Canon	Bubblejet	BJC-4200 Photo	10
Canon	Bubblejet	BJC-4200sp	10
Canon	Bubblejet	BJC-4204	10
Canon	Bubblejet	BJC-420j	10
Canon	Bubblejet	BJC-4300	10
Canon	Bubblejet	BJC-4302	10
Canon	Bubblejet	BJC-4304	10
Canon	Bubblejet	BJC-4304 Photo	10
Canon	Bubblejet	BJC-430j	10
Canon	Bubblejet	BJC-4310	10
Canon	Bubblejet	BJC-4400	10
Canon	Bubblejet	BJC-4550	10
Canon	Bubblejet	BJC-4650	10
Canon	Bubblejet	BJC-50	11
Canon	Bubblejet	BJC-5100	10
Canon	Bubblejet	BJC-55	11
Canon	Bubblejet	BJC-5500	10
Canon	Bubblejet	BJC-60	9
Canon	Bubblejet	BJC-600	8
Canon	Bubblejet	BJC-6000	22
Canon	Bubblejet	BJC-600e	8
Canon	Bubblejet	BJC-610	8
Canon	Bubblejet	BJC-6100	22
Canon	Bubblejet	BJC-620	8
Canon	Bubblejet	BJC-6200	22
Canon	Bubblejet	BJC-6200s	22
Canon	Bubblejet	BJC-630	8
Canon	Bubblejet	BJC-6500	22
Canon	Bubblejet	BJC-680	8
Canon	Bubblejet	BJC-70	11

Canon	Bubblejet	BJC-80	11
Canon	Bubblejet	BJC-800	8
Canon	Bubblejet	BJC-800j	8
Canon	Bubblejet	BJC-820	8
Canon	Bubblejet	BJC-8200	22
Canon	Bubblejet	BJC-8200p	22
Canon	Bubblejet	BJC-820j	8
Canon	Bubblejet	BJC-85	11
Canon	Bubblejet	BJC-8500	22
Canon	Bubblejet	BJC-85w	11
Canon	Bubblejet	BJC-880	8
Canon	Bubblejet	BJC-880j	8
Canon	Bubblejet	BJC-95	9
Canon	Bubblejet	BJF-850	22
Canon	Bubblejet	BJPC-80	8
Canon	Bubblejet	BJPC-81	8
Canon	Bubblejet	i250	10
Canon	Bubblejet	i255	10
Canon	Bubblejet	i320	10
Canon	Bubblejet	i350	10
Canon	Bubblejet	i355	10
Canon	Bubblejet	i450	10
Canon	Bubblejet	i450x	10
Canon	Bubblejet	i455	10
Canon	Bubblejet	i470d	10
Canon	Bubblejet	i475d	10
Canon	Bubblejet	i550	22
Canon	Bubblejet	i550x	22
Canon	Bubblejet	i5550	22
Canon	Bubblejet	i560	22
Canon	Bubblejet	i6100	22
Canon	Bubblejet	i6500	22
Canon	Bubblejet	i850	22
Canon	Bubblejet	i860	22
Canon	Bubblejet	i865	22
Canon	Bubblejet	i900	22
Canon	Bubblejet	i905	22
Canon	Bubblejet	i9100	22
Canon	Bubblejet	i950	22
Canon	Bubblejet	i950d	22
Canon	Bubblejet	i965	22
Canon	Bubblejet	i990	22
Canon	Bubblejet	i9950	22
Canon	Bubblejet	MPC-190s	10

Canon	Bubblejet	P670	8
Canon	Bubblejet	Pro-5000	9
Canon	Bubblejet	Pro-7000	9
Canon	Bubblejet	S100	10
Canon	Bubblejet	S200	10
Canon	Bubblejet	S200spx	10
Canon	Bubblejet	S200x	10
Canon	Bubblejet	S300	10
Canon	Bubblejet	S330	10
Canon	Bubblejet	S330d	10
Canon	Bubblejet	S400	22
Canon	Bubblejet	S400x	22
Canon	Bubblejet	S450	22
Canon	Bubblejet	S4500	22
Canon	Bubblejet	S500	22
Canon	Bubblejet	S520	22
Canon	Bubblejet	S520x	22
Canon	Bubblejet	S530d	22
Canon	Bubblejet	S600	22
Canon	Bubblejet	S630	22
Canon	Bubblejet	S6300	22
Canon	Bubblejet	S750	22
Canon	Bubblejet	S800	22
Canon	Bubblejet	S820	22
Canon	Bubblejet	S8200	22
Canon	Bubblejet	S820d	22
Canon	Bubblejet	S830	22
Canon	Bubblejet	S830d	22
Canon	Bubblejet	S900	22
Canon	Bubblejet	S9000	22
Canon	Bubblejet	BJC-7000	~
Canon	Bubblejet	BJC-7002	~
Canon	Bubblejet	BJC-7004	~
Canon	Bubblejet	BJC-7005	~
Canon	Bubblejet	BJC-7100	~
Canon	Bubblejet	BJC-8000	~
Canon	Bubblejet	i70	~
Canon	Bubblejet	i80	~
Canon	Bubblejet	i90	~
Canon	Fax	BN-200c	11
Canon	Fax	BN-700c	11
Canon	Fax	BN-750c	11
Canon	Fax	B-60	9
Canon	Fax	B-70	9

Canon	Fax	B-75	9
Canon	Fax	B-160	9
Canon	Fax	B-170	9
Canon	Fax	B-190	9
Canon	Fax	B-200	9
Canon	Fax	B-200e	9
Canon	Fax	B-200f	9
Canon	Fax	B-220	9
Canon	Fax	B-230	9
Canon	Fax	B-320	9
Canon	Fax	B-340	9
Canon	Fax	B-360	9
Canon	Fax	B-200s	9
Canon	Fax	B-405	9
Canon	Fax	B-210c	10
Canon	Fax	B-215c	10
Canon	Fax	EB-10	10
Canon	Fax	B-740	10
Canon	Fax	B-380if	10
Canon	Fax	B-180c	10
Canon	Fax	B-230c	10
Canon	Fax	BI-60	10
Canon	Fax	BI-80c	10
Canon	Fax	MPC-70	10
Canon	Fax	MPC-545	10
Canon	Fax	EB-15	10
Canon	Fax	LR-1	11
Canon	Fax	CF H1	11
Canon	Fax	CF H1 CL	11
Canon	Fax	CLC-7	18
Canon	Fax	CLC-10	18
Canon	Fax	CJ-7	18
Canon	Fax	CJ-10	18
Canon	Fax	B-100	18
Canon	Fax	B-110	18
Canon	Fax	B-150	18
Canon	Fax	B-155	18
Canon	Fax	B-540	18
Canon	Fax	B-550	18
Canon	Fax	B-600	18
Canon	Fax	B-640	18
Canon	Fax	B-650	18
Canon	Fax	B-840	18
Canon	Fax	B-115	18

Canon	Fax	B-120	18
Canon	Fax	B-140	18
Canon	Fax	B-820	18
Canon	Fax	BN-22	~
Canon	Fax	BN-32p	~
Canon	Fax	BN-100c	~
Canon	Fax	BN-120c	~
Canon	Fax	BN-600	~
Canon	Fax	BP-10d	~
Canon	Fax	BP-12d	~
Canon	Fax	BP-25d	~
Canon	Fax	BP-26d	~
Canon	Fax	BP-35d	~
Canon	Fax	BP-36d	~
Canon	Fax	BP-1025d	~
Canon	Fax	BP-1211d	~
Canon	Fax	BP-1225d	~
Canon	Fax	BP-1425d	~
Canon	Fax	BP-1445d	~
Canon	Fax	BP-5020d	~
Canon	Fax	BP-5220d	~
Canon	Fax	BP-5420d	~
Canon	Innova	BJT-800p	11
Canon	Innova	Note 500J800	11
Canon	Mono	~	18
Canon	Multipass	BJ-S	9
Canon	Multipass	BJ -SE	9
Canon	Multipass	1000	9
Canon	Multipass	BJC-2600	10
Canon	Multipass	BJC-3500	10
Canon	Multipass	BJC-5000	10
Canon	Multipass	C-10	10
Canon	Multipass	C-20	10
Canon	Multipass	C-30	10
Canon	Multipass	C-70	10
Canon	Multipass	C75	10
Canon	Multipass	C-80	10
Canon	Multipass	C-530	10
Canon	Multipass	C-545	10
Canon	Multipass	C-555	10
Canon	Multipass	C-560	10
Canon	Multipass	C-635	10
Canon	Multipass	C-2500	10

Canon	Multipass	C-3000	10
Canon	Multipass	C-3500	10
Canon	Multipass	C-4000	10
Canon	Multipass	C-5000	10
Canon	Multipass	C-5500	10
Canon	Multipass	C-6000	10
Canon	Multipass	F-20	10
Canon	Multipass	MPC-190	10
Canon	Multipass	MPC-200	10
Canon	Multipass	C-800	18
Canon	Multipass	C-100	22
Canon	Multipass	C-400	22
Canon	Multipass	C-600	22
Canon	Multipass	C-755	22
Canon	Multipass	F-30	22
Canon	Multipass	F-50	22
Canon	Multipass	F-60	22
Canon	Multipass	F-80	22
Canon	Multipass	MP-700	22
Canon	Multipass	MP-730	22
Canon	Navigator	VP-500	9
Canon	Navigator	HD-40	9
Canon	Notejet	III	11
Canon	Notejet	IIIcx	11
Canon	Notejet	Intel DX4	11
Canon	Notejet	~	11
Canon	Notejet	486	11
Canon	Notejetii	486c	11
Canon	Pixma	MP-130	10
Canon	Pixma	MP-110	10
Canon	Pixma	iP1000	10
Canon	Pixma	iP1500	10
Canon	Pixma	iP2000	10
Canon	Pixma	MP-750	22
Canon	Pixma	MP-780	22
Canon	Pixma	MP-760	22
Canon	Pixma	iP4000r	22
Canon	Pixma	iP8500	22
Canon	Pixma	iP8500d	22
Canon	Pixma	iP3000	22
Canon	Pixma	iP4000	22
Canon	Pixma	iP5000	22
Canon	Pixma	iP6000d	22
Canon	Pixma	iP1200	~

Canon	Pixma	iP1600	~
Canon	Pixma	MP-150	~
Canon	Pixma	MP-170	~
Canon	Pixma	MP-450	~
Canon	Pixma	iP2200	~
Canon	Pixma	MP-500	~
Canon	Pixma	MP-800	~
Canon	Pixma	iP5200r	~
Canon	Smartbase	MP-360	10
Canon	Smartbase	MP-200	10
Canon	Smartbase	MP-360	10
Canon	Smartbase	MP-370	10
Canon	Smartbase	MP-390	10
Canon	Smartbase	MPC-390	10
Canon	Smartbase	MP-730 Photo	22
Canon	Smartbase	MPC-400	22
Canon	Smartbase	MPC-600	22
Canon	Smartbase	MP-700 Photo	22
Canon	Starwriter	400	9
Canon	Starwriter	60-WP	9
Canon	Starwriter	70-WP	9
Canon	Starwriter	80-WP	9
Canon	Starwriter	85-WP	9
Canon	Starwriter	95-WP	9
Canon	Starwriter	80 Deluxe	9
Canon	Starwriter	500	9
Canon	Starwriter	Pro-2000	9
Canon	Starwriter	Jet-400	11
Canon	Starwriter	550c	11
Canon	Starwriter	Jet-300	11
Canon	Starwriter	Jet-350	11
Canon	Starwriter	Jet-4000	11
Canon	Thinkpad	550-BJ	~
Canon	Pixma	iP4200	~
Canon	Fax	B120	18
Canon	Fax	B150	18
Canon	Fax	B160	10
Canon	Fax	B180c	10
Canon	Fax	B210c	10
Canon	Fax	BJC265sp	18
Canon	Bubblejet	i9900	22
Canon	Pixma	iP6210d	~
Canon	Pixma	iP6220d	~

Canon	Pixma	iP6600d	~
Canon	Pixma	iP90	~
Canon	Companion	BN700	11
Canon	Fax	B310	9
Canon	Fax	B340F	9
Canon	Fax	B400	9
Canon	Fax	MP10	18
Canon	SELPHY	DS700	~
Canon	SELPHY	DS810	~
Canon	Smartbase	MPC600f	22
Canon	Starwriter	JET 500	11
Canon	Starwriter	JET 550c	11
Canon	Starwriter	1500	9

	Not Refillable
	Separate Instructions
	Checking For Updates
	NEW
	Cannot Refill Originals
	Ammendments

Printer Type	Printer Model	Series	Page Number
Compaq	~	IJ-200	12
Compaq	~	IJ-300	12
Compaq	~	IJ-600	12
Compaq	~	IJ-700	12
Compaq	~	IJ-750	12
Compaq	~	IJ-900	12
Compaq	~	IJ-1000	12
Compaq	~	IJ-1200	12
Compaq	Pagemaster	201	12
Compaq	All in One	A1000	12
Compaq	~	A900	12
Compaq	Three in one	C3-1000	12
Compaq	Multifunction	A1500	12
Compaq	~	1400p	12
Compaq	~	IJ 650	14
Compaq	~	IJ - 1400p	12
Compaq	~	A3000	12
Compaq	~	A4000	12

	Not Refillable
	Separate Instructions
	Checking For Updates
	NEW
	Cannot Refill Originals
	Ammendments

Printer Type	Series Type	Printer Model	Page No
Dell	~	720	14
Dell	~	J740	13
Dell	~	A920	14
Dell	~	A940	13
Dell	*	A960	13
Dell	All in one	922	~
Dell	All in one	942	~
Dell	All in one	962	~
Dell	All in one	924	~
Dell	All in one	944	~
Dell	All in one	964	~

	Not Refillable
	Separate Instructions
	Checking For Updates
	NEW
	Cannot Refill Originals
	Ammendments

*** = Zap-it required**

Printer	Printer Type	Model No	Page No
Epson	Stylus Colour	C20	5
Epson	Stylus Colour	C20ux	5
Epson	Stylus Colour	C32*	5
Epson	Stylus Colour	C40	5
Epson	Stylus Colour	C40sx	5
Epson	Stylus Colour	C40ux	5
Epson	Stylus Colour	C42*	5
Epson	Stylus Colour	C42+*	5
Epson	Stylus Colour	C42s*	5
Epson	Stylus Colour	C42sx*	5
Epson	Stylus Colour	C42ux*	5
Epson	Stylus Colour	C44*	5
Epson	Stylus Colour	C44UX*	5
Epson	Stylus Colour	C41*	5
Epson	Stylus Colour	C43*	5
Epson	Stylus Colour	C43ux*	5
Epson	Stylus Colour	C46*	5
Epson	Stylus Colour	C50*	5

Epson	Stylus Colour	C60*	5
Epson	Stylus Colour	C61*	5
Epson	Stylus Colour	C62*	5
Epson	Stylus Photo	915*	5
Epson	Stylus Photo	925*	5
Epson	Stylus Photo	935*	5
Epson	Stylus Photo	952	5
Epson	Stylus Colour /All in One	CX3100*	5
Epson	Stylus Colour	CX3200*	5
Epson	Stylus Colour	300	5
Epson	Stylus Colour	400	5 Bk / 6 Clr
Epson	Stylus Colour	440	5
Epson	Stylus Colour	440tv	5
Epson	Stylus Colour	460	5
Epson	Stylus Colour	480	5
Epson	Stylus Colour	480sx	5
Epson	Stylus Colour	480sxu	5
Epson	Stylus Colour	500	5 Bk / 6 Clr
Epson	Stylus Colour	580	5
Epson	Stylus Colour	600	5
Epson	Stylus Colour	600q	5
Epson	Stylus Colour	640	5
Epson	Stylus Colour	660	5
Epson	Stylus Colour	670	5
Epson	Stylus Colour	680*	5
Epson	Stylus Colour	685*	5
Epson	Stylus Colour	700	5
Epson	Stylus Colour	710	5
Epson	Stylus Colour	740	5
Epson	Stylus Colour	750	5
Epson	Stylus Colour	750tv	5
Epson	Stylus Colour	760	5
Epson	Stylus Colour	777*	5
Epson	Stylus Colour	777i*	5
Epson	Stylus Colour	780*	5
Epson	Stylus Colour	785epx*	5
Epson	Stylus Colour	790*	5
Epson	Stylus Colour	795*	5
Epson	Stylus Colour	300	5
Epson	Stylus Photo	810*	5
Epson	Stylus Photo	820	5
Epson	Stylus Photo	830*	5

Epson	Stylus Photo	830u*	5
Epson	Stylus Colour	840	5
Epson	Stylus Colour	860	5
Epson	Stylus Photo	870*	5
Epson	Stylus Photo	870le*	5
Epson	Stylus Photo	875dc*	5
Epson	Stylus Colour	880	5
Epson	Stylus Colour	880i	5
Epson	Stylus Colour	880t	5
Epson	Stylus Photo	890*	5
Epson	Stylus Photo	895*	5
Epson	Stylus Colour	900	5
Epson	Stylus Colour	900g	5
Epson	Stylus Colour	900n	5
Epson	Stylus Photo	900*	5
Epson	Stylus Colour	980	5
Epson	Stylus Colour	980n	5
Epson	Stylus Colour	1160	5
Epson	Stylus Photo	1200	5
Epson	Stylus Photo	1270*	5
Epson	Stylus Photo	1280*	5
Epson	Stylus Photo	1290*	5
Epson	Stylus Photo	1290S*	5
Epson	Stylus Photo	2000P*	5
Epson	Stylus Scan	2000	5
Epson	Stylus Scan	2500	5
Epson	Stylus Colour	Photo	5
Epson	Stylus Colour	Photo ex	5
Epson	Stylus Colour	PM 700	5
Epson	Stylus Colour	PM2000	5
Epson	Stylus Colour	MJ510	5 Bk / 6 Clr
Epson	Stylus Colour	MJ810	5 Bk / 6 Clr
Epson	Stylus Colour	MJ1000	5
Epson	Stylus Colour	1500	8 Black 6 Colour
Epson	Stylus Colour	820	6
Epson	Stylus Colour	200	6
Epson	Stylus Colour	II	6
Epson	Stylus Colour	IIs	6
Epson	Stylus Colour	800	7 Bk / 5Clr
Epson	Stylus Colour	800+	7 Bk / 5Clr
Epson	Stylus Colour	800N	7 Bk / 5Clr

Epson	Stylus Colour	850	7 Bk / 5Clr
Epson	Stylus Colour	1000+	7 Bk / 5Clr
Epson	Stylus Colour	1520	7 Bk / 5Clr
Epson	Stylus Colour	1520K+	7 Bk / 5Clr
Epson	Stylus Colour	Pro 5500	8
Epson	Stylus Colour	Pro 7000s	8
Epson	Stylus Colour	Pro 7500	8
Epson	Stylus Photo	Pro 7600	8
Epson	Stylus Colour	Pro 9000	7
Epson	Stylus Colour	Pro 9500	7
Epson	Stylus Photo	Pro 9600	8
Epson	Stylus Photo	Pro 10000	8
Epson	Stylus Colour	Pro 10000cf	8
Epson	Stylus Colour	Pro 10600	8
Epson	Stylus Colour	Colour	7
Epson	Stylus Colour	Pro	7
Epson	Stylus Colour	Pro XL	7
Epson	Stylus Colour	Pro XL+	7
Epson	Stylus Colour	MJ101	7
Epson	Stylus Colour	MJ450	7
Epson	Stylus Colour	MJ500	7
Epson	Stylus Colour	MJ700	7
Epson	Stylus Colour	MJ900	7
Epson	Stylus Colour	MJ910	7
Epson	Stylus Colour	MJ930	7 Bk / 5Clr
Epson	Stylus Colour	MJ1010	7
Epson	Stylus Colour	MJ1050	7
Epson	Stylus Colour	MJ1100	7
Epson	Stylus Colour	MJ3000	6
Epson	Stylus Colour	MJ5000	7
Epson	Stylus Colour	MJ5100	7
Epson	Stylus Colour	MJ8000	8
Epson	Stylus Colour	4000 Proofer	8
Epson	Stylus Colour	5500 Proofer	8
Epson	Stylus Photo	7000 Proofer	8
Epson	Stylus Colour	7000s Proofer	8
Epson	Stylus Colour	7500 Proofer	8
Epson	Stylus Colour	7500s Proofer	8
Epson	Stylus Colour	7600 Proofer	8
Epson	Stylus Photo	9000 Proofer	8
Epson	Stylus Colour	9500 Proofer	8
Epson	Stylus Colour	9600 Proofer	8
Epson	Stylus Colour	SQ-1170	8
Epson	Stylus Colour	SQ-2500	8

Epson	Stylus Colour	SQ-2550	8
Epson	Stylus Colour	SQ-850	8
Epson	Stylus Colour	SQ-870	8
Epson	Stylus Colour	PM5000	8
Epson	Stylus Colour	3000	8
Epson	Stylus Colour	Pro 5000	8
Epson	Stylus Colour	P860a	7
Epson	Stylus Photo	950*	~
Epson	Stylus Photo	960*	~
Epson	Stylus Photo	2100*	~
Epson	Stylus Photo	2200*	~
Epson	Stylus Colour	C70*	~
Epson	Stylus Colour	C70 +*	~
Epson	Stylus Colour	C80*	~
Epson	Stylus Colour	C80n*	~
Epson	Stylus Colour	C80wn*	~
Epson	Stylus Colour	C90*	~
Epson	Stylus Colour	C90+*	~
Epson	Stylus Colour	C63*	~
Epson	Stylus Colour	C64*	~
Epson	Stylus Colour	C66*	~
Epson	Stylus Colour	C82*	~
Epson	Stylus Colour	C83*	~
Epson	Stylus Colour	C84*	~
Epson	Stylus Colour	C86*	~
Epson	Stylus Colour	C86* Photo	~
Epson	Stylus	CX3600*	~
Epson	Stylus	CX3650*	~
Epson	Stylus	CX4600*	~
Epson	Stylus Colour/All in one	CX5100*	~
Epson	Stylus Colour	CX5200*	~
Epson	Stylus Colour	CX5300*	~
Epson	Stylus Colour	CX5400*	~
Epson	Stylus Colour	CX6400*	~
Epson	Stylus Colour	CX6600*	~
Epson	Stylus Photo	R200*	~
Epson	Stylus Photo	R210*	~
Epson	Stylus Photo	R300*	~
Epson	Stylus Photo	R310*	~
Epson	Stylus Photo	R320*	~
Epson	Stylus Photo	R800*	~
Epson	Stylus Photo	R1800*	~
Epson	Stylus Colour	RX420*	~
Epson	Stylus Colour	RX425*	~

Epson	Stylus Colour	RX500*	~
Epson	Stylus Colour	RX510*	~
Epson	Stylus Colour	RX600'	~
Epson	Stylus Photo	RX620*	~
Epson	Stylus Photo	RX700	~
Epson	Epson	R2400*	~
Epson	Stylus Photo	R220*	~
Epson	Stylus Photo	R340*	~
Epson	Stylus Photo	RX520*	~
Epson	DX Series	DX4200*	~
Epson	DX Series	DX4800*	~
Epson	DX Series	DX4850*	~
Epson	DX Series	DX3800*	~
Epson	DX Series	DX3850*	~
Epson	D Series	D68*	~
Epson	D Series	D88*	~
Epson	Stylus Photo	R240*	~
Epson	Stylus	C48*	5
Epson	Picture Mate	100	N/R
Epson	Picture Mate	~	N/R
Epson	Picture Mate	Mobile Phone Edition	N/R
Epson	Stylus	C45*	5
Epson	Stylus	CX1500*	5
Epson	Stylus	CX4500*	~
Epson	Stylus Photo	RX245*	~
Epson	Stylus Scan	2000	7 Bk / 5Clr
Epson	Stylus Scan	2500	7 Bk / 5Clr

	Not Refillable
	Separate Instructions
	Checking For Updates
	NEW
	Cannot Refill Originals
	Ammendments

Printer Type	Printer Type	Series	Page Number
Hewlett Packard	Fax	1010	1
Hewlett Packard	Fax	1020	1
Hewlett Packard	Deskjet	Portable	1
Hewlett Packard	Designjet	200	1 & 2
Hewlett Packard	Designjet	200d	1 & 2
Hewlett Packard	Designjet	200e	1 & 2
Hewlett Packard	Deskjet	310	1 & 2
Hewlett Packard	Deskjet	311	1 & 2
Hewlett Packard	Deskjet	320	1 & 2
Hewlett Packard	Deskjet	340	1 & 2
Hewlett Packard	Deskjet	340cbi	1 & 2
Hewlett Packard	Deskjet	340cm	1 & 2
Hewlett Packard	Deskjet	340cv	1 & 2
Hewlett Packard	Deskjet	350c	1 & 2
Hewlett Packard	Deskjet	350cbi	1 & 2
Hewlett Packard	Deskjet	400	1 & 2
Hewlett Packard	Deskjet	400L	1 & 2
Hewlett Packard	Deskjet	400c	1 & 2
Hewlett Packard	Deskjet	420	1 & 2
Hewlett Packard	Deskjet	420c	1 & 2
Hewlett Packard	Deskjet	500	1 & 2
Hewlett Packard	Deskjet	510	1 & 2

Hewlett Packard	Deskjet	500c	1 & 2
Hewlett Packard	Deskjet	500p	1 & 2
Hewlett Packard	Deskjet	520	1 & 2
Hewlett Packard	Deskjet	540	1 & 2
Hewlett Packard	Deskjet	550c	1 & 2
Hewlett Packard	Deskjet	560c	1 & 2
Hewlett Packard	Deskjet	560j	1 & 2
Hewlett Packard	Deskjet	570	1 & 2
Hewlett Packard	Deskjet	600	1 & 2
Hewlett Packard	Deskjet	600c	1 & 2
Hewlett Packard	Deskjet	610	1 & 2
Hewlett Packard	Deskjet	610c	1 & 2
Hewlett Packard	Deskjet	610cl	1 & 2
Hewlett Packard	Deskjet	612c	1 & 2
Hewlett Packard	Deskjet	630c	1 & 2
Hewlett Packard	Deskjet	632c	1 & 2
Hewlett Packard	Deskjet	640c	1 & 2
Hewlett Packard	Deskjet	640u	1 & 2
Hewlett Packard	Deskjet	642c	1 & 2
Hewlett Packard	Deskjet	648c	1 & 2
Hewlett Packard	Deskjet	656c	1 & 2
Hewlett Packard	Deskjet	660c	1 & 2
Hewlett Packard	Deskjet	670tv	1 & 2
Hewlett Packard	Deskjet	670c	1 & 2
Hewlett Packard	Deskjet	670k	1 & 2
Hewlett Packard	Deskjet	672c	1 & 2
Hewlett Packard	Deskjet	680c	1 & 2
Hewlett Packard	Deskjet	682c	1 & 2
Hewlett Packard	Deskjet	690c	1 & 2
Hewlett Packard	Deskjet	692c	1 & 2
Hewlett Packard	Deskjet	693c	1 & 2
Hewlett Packard	Deskjet	694c	1 & 2
Hewlett Packard	Deskjet	695c	1 & 2
Hewlett Packard	Deskjet	697c	1 & 2
Hewlett Packard	Deskwriter	310	1 & 2
Hewlett Packard	Deskwriter	320	1 & 2
Hewlett Packard	Deskwriter	340	1 & 2
Hewlett Packard	Deskwriter	400	1 & 2
Hewlett Packard	Deskwriter	500	1 & 2
Hewlett Packard	Deskwriter	510	1 & 2
Hewlett Packard	Deskwriter	520	1 & 2
Hewlett Packard	Deskwriter	540	1 & 2
Hewlett Packard	Deskwriter	550c	1 & 2
Hewlett Packard	Deskwriter	560	1 & 2

Hewlett Packard	Deskwriter	560c	1 & 2
Hewlett Packard	Deskwriter	600	1 & 2
Hewlett Packard	Deskwriter	600cse	1 & 2
Hewlett Packard	Deskwriter	660c	1 & 2
Hewlett Packard	Deskwriter	672c	1 & 2
Hewlett Packard	Deskwriter	680c	1 & 2
Hewlett Packard	Deskwriter	682	1 & 2
Hewlett Packard	Deskwriter	682c	1 & 2
Hewlett Packard	Deskwriter	690c	1 & 2
Hewlett Packard	Deskwriter	694c	1 & 2
Hewlett Packard	Fax	200	1 & 2
Hewlett Packard	Fax	200vp	1 & 2
Hewlett Packard	Fax	300	1 & 2
Hewlett Packard	Fax	310	1 & 2
Hewlett Packard	Fax	700	1 & 2
Hewlett Packard	Fax	700vp	1 & 2
Hewlett Packard	Fax	750	1 & 2
Hewlett Packard	Fax	800	1 & 2
Hewlett Packard	Fax	900	1 & 2
Hewlett Packard	Fax	900vp	1 & 2
Hewlett Packard	Fax	910	1 & 2
Hewlett Packard	Fax	920	1 & 2
Hewlett Packard	Fax	950	1 & 2
Hewlett Packard	Officejet	LX	1 & 2
Hewlett Packard	Officejet	310	1 & 2
Hewlett Packard	Officejet	320	1 & 2
Hewlett Packard	Officejet	330	1 & 2
Hewlett Packard	Officejet	350	1 & 2
Hewlett Packard	Officejet	500	1 & 2
Hewlett Packard	Officejet	520	1 & 2
Hewlett Packard	Officejet	570	1 & 2
Hewlett Packard	Officejet	580	1 & 2
Hewlett Packard	Officejet	590	1 & 2
Hewlett Packard	Officejet	600	1 & 2
Hewlett Packard	Officejet	610	1 & 2
Hewlett Packard	Officejet	630	1 & 2
Hewlett Packard	Officejet	635	1 & 2
Hewlett Packard	Officejet	700	1 & 2
Hewlett Packard	Officejet	710	1 & 2
Hewlett Packard	Officejet	720	1 & 2
Hewlett Packard	PSC	300	1 & 2
Hewlett Packard	PSC	380	1 & 2
Hewlett Packard	Quietjet	370	1 & 2
Hewlett Packard	Officejet	7100	3

Hewlett Packard	cp	1160	3
Hewlett Packard	cp	1160tn	3
Hewlett Packard	Digital Copier/printer	610	3
Hewlett Packard	Officejet	D125xi	3
Hewlett Packard	Officejet	D130	3
Hewlett Packard	Officejet	D135	3
Hewlett Packard	Officejet	D145	3
Hewlett Packard	Officejet	D155xi	3
Hewlett Packard	Officejet	7110	3
Hewlett Packard	Officejet	7130	3
Hewlett Packard	Officejet	7130xi	3
Hewlett Packard	Officejet	7140xi	3
Hewlett Packard	Digital Copier/printer	410	4
Hewlett Packard	Deskjet	450	4
Hewlett Packard	Deskjet	450wbt	4
Hewlett Packard	Deskjet	450cbi	4
Hewlett Packard	Deskjet	450ci	4
Hewlett Packard	Deskjet	3320	4
Hewlett Packard	Deskjet	3325	4
Hewlett Packard	Deskjet	3420	4
Hewlett Packard	Deskjet	3425	4
Hewlett Packard	Deskjet	3450	4
Hewlett Packard	Deskjet	3520	4
Hewlett Packard	Deskjet	3550	4
Hewlett Packard	Deskjet	3600	4
Hewlett Packard	Deskjet	3650	4
Hewlett packard	Deskjet	3740	4
Hewlett Packard	Deskjet	3745	4
Hewlett Packard	Deskjet	3840	4
Hewlett Packard	Deskjet	3845	4
Hewlett Packard	Deskjet	5100	4
Hewlett Packard	Deskjet	5150	4
Hewlett Packard	Deskjet	5550	4
Hewlett Packard	Deskjet	5551	4
Hewlett Packard	Deskjet	5552	4
Hewlett Packard	Deskjet	5600	4
Hewlett Packard	Deskjet	5650	4
Hewlett Packard	Deskjet	5652	4
Hewlett Packard	Deskjet	5850	4
Hewlett Packard	Deskjet	9600	4
Hewlett Packard	Deskjet	9650	4
Hewlett Packard	Deskjet	9670	4
Hewlett Packard	Deskjet	9680	4
Hewlett Packard	Officejet	4110	4

Hewlett Packard	Officejet All- In-One	5500	4
Hewlett Packard	Officejet	5508	4
Hewlett Packard	Officejet	5510	4
Hewlett Packard	Officejet	5515	4
Hewlett Packard	Officejet	6100	4
Hewlett Packard	Officejet	6110	4
Hewlett Packard	Officejet	6110xi	4
Hewlett Packard	~	P7660	4
Hewlett Packard	Officejet PFSC	4200	4
Hewlett Packard	PSC	1110	4
Hewlett Packard	PSC	1200	4
Hewlett Packard	PSC	1205	4
Hewlett Packard	PSC	1210	4
Hewlett Packard	PSC	1215	4
Hewlett Packard	PSC	1300	4
Hewlett Packard	PSC	1310	4
Hewlett Packard	PSC	1315	4
Hewlett Packard	PSC	1350	4
Hewlett Packard	PSC	1355	4
Hewlett Packard	PSC	2105	4
Hewlett Packard	PSC	2110	4
Hewlett Packard	PSC	2110v	4
Hewlett Packard	PSC	2110xi	4
Hewlett Packard	PSC	2115	4
Hewlett Packard	PSC	2170	4
Hewlett Packard	PSC	2175	4
Hewlett Packard	PSC	2175v	4
Hewlett Packard	PSC	2175xi	4
Hewlett Packard	PSC	2179i	4
Hewlett Packard	PSC	2210	4
Hewlett Packard	PSC	2400	4
Hewlett Packard	PSC	2405	4
Hewlett Packard	PSC	2410	4
Hewlett Packard	PSC	2500	4
Hewlett Packard	Photosmart	100	4
Hewlett Packard	Photosmart	130	4
Hewlett Packard	Photosmart	140	4
Hewlett Packard	Photosmart	145	4
Hewlett Packard	Photosmart	230	4
Hewlett Packard	Photosmart	240	4
Hewlett Packard	Photosmart	245	4
Hewlett Packard	Photosmart	7150	4
Hewlett Packard	Photosmart	7200	4
Hewlett Packard	Photosmart	7260	4

Hewlett Packard	Photosmart	7350	4
Hewlett Packard	Photosmart	7400	4
Hewlett Packard	Photosmart	7450	4
Hewlett Packard	Photosmart	7550	4
Hewlett Packard	Photosmart	7600	4
Hewlett Packard	Photosmart	7660	4
Hewlett Packard	Photosmart	7700	4
Hewlett Packard	Photosmart	7760	4
Hewlett Packard	Photosmart	7762	4
Hewlett Packard	Photosmart	7900	4
Hewlett Packard	Photosmart	7960	4
Hewlett Packard	Thinkjet	2510	4
Hewlett Packard	Photosmart	P230	4
Hewlett Packard	Photosmart	P245	4
Hewlett Packard	Photosmart	P7450	4
Hewlett Packard	Photosmart	P7550	4
Hewlett Packard	Photosmart	7960 GP	4
Hewlett Packard	PSC	1311	4
Hewlett Packard	PSC	1209	4
Hewlett Packard	Deskjet	3843	4
Hewlett Packard	Photosmart	7755	4
Hewlett Packard	PSC	1317	4
Hewlett Packard	Photosmart	7345	4
Hewlett Packard	PSC	1219	4
Hewlett Packard	Officejet	2455	4
Hewlett Packard	Deskjet	3743	4
Hewlett Packard	Deskjet	3744	4
Hewlett Packard	ColorCopier	210	15
Hewlett Packard	Copyjet	~	15
Hewlett Packard	Copyjet	M	15
Hewlett Packard	Designjet	220	15
Hewlett Packard	Designjet	230	15
Hewlett Packard	Designjet	250c	15
Hewlett Packard	Designjet	330	15
Hewlett Packard	Designjet	330d	15
Hewlett Packard	Designjet	350c	15
Hewlett Packard	Designjet	430c	15
Hewlett Packard	Designjet	450c	15
Hewlett Packard	Designjet	455ca	15
Hewlett Packard	Designjet	488ca	15
Hewlett Packard	Designjet	650c	15
Hewlett Packard	Designjet	650c/ps	15
Hewlett Packard	Designjet	650ce	15
Hewlett Packard	Designjet	700	15

Hewlett Packard	Designjet	750c	15
Hewlett Packard	Designjet	750c+	15
Hewlett Packard	Designjet	755cm	15
Hewlett Packard	Designjet	1050	15
Hewlett Packard	Designjet	1055	15
Hewlett Packard	Designjet	2000cp	15
Hewlett Packard	Designjet	2500cp	15
Hewlett Packard	Designjet	2800CP Wide	15
Hewlett Packard	Designjet	3000CP Wide	15
Hewlett Packard	Designjet	3500cp	15
Hewlett Packard	Designjet	3800CP Wide	15
Hewlett Packard	Deskjet	1200c	15
Hewlett Packard	Deskjet	1200c/ps	15
Hewlett Packard	Deskjet	1600c	15
Hewlett Packard	Deskjet	1600m	15
Hewlett Packard	Deskjet	1600n	15
Hewlett Packard	ColorCopier	110	15&16
Hewlett Packard	ColorCopier	120	15&16
Hewlett Packard	ColorCopier	140	15&16
Hewlett Packard	ColorCopier	145	15&16
Hewlett Packard	ColorCopier	150	15&16
Hewlett Packard	ColorCopier	155	15&16
Hewlett Packard	ColorCopier	160	15&16
Hewlett Packard	ColorCopier	170	15&16
Hewlett Packard	ColorCopier	180	15&16
Hewlett Packard	ColorCopier	190	15&16
Hewlett Packard	ColorCopier	260	15&16
Hewlett Packard	ColorCopier	270	15&16
Hewlett Packard	ColorCopier	280	15&16
Hewlett Packard	ColorCopier	290	15&16
Hewlett Packard	ColorCopier	700	15&16
Hewlett Packard	Deskjet	710	15&16
Hewlett Packard	Deskjet	710c	15&16
Hewlett Packard	Deskjet	712c	15&16
Hewlett Packard	Deskjet	720	15&16
Hewlett Packard	Deskjet	720c	15&16
Hewlett Packard	Deskjet	722c	15&16
Hewlett Packard	Deskjet	810	15&16
Hewlett Packard	Deskjet	810c	15&16
Hewlett Packard	Deskjet	812c	15&16
Hewlett Packard	Deskjet	815c	15&16

Hewlett Packard	Deskjet	820cse	15&16
Hewlett Packard	Deskjet	820cxi	15&16
Hewlett Packard	Deskjet	820c	15&16
Hewlett Packard	Deskjet	820csi	15&16
Hewlett Packard	Deskjet	830c	15&16
Hewlett Packard	Deskjet	832c	15&16
Hewlett Packard	Deskjet	840c	15&16
Hewlett Packard	Deskjet	841c	15&16
Hewlett Packard	Deskjet	842c	15&16
Hewlett Packard	Deskjet	843c	15&16
Hewlett Packard	Deskjet	845c	15&16
Hewlett Packard	Deskjet	850c	15&16
Hewlett Packard	Deskjet	855c	15&16
Hewlett Packard	Deskjet	855cse	15&16
Hewlett Packard	Deskjet	855csi	15&16
Hewlett Packard	Deskjet	855cxi	15&16
Hewlett Packard	Deskjet	865cse	15&16
Hewlett Packard	Deskjet	870cse	15&16
Hewlett Packard	Deskjet	870cxi	15&16
Hewlett Packard	Deskjet	880c	15&16
Hewlett Packard	Deskjet	882c	15&16
Hewlett Packard	Deskjet	890c	15&16
Hewlett Packard	Deskjet	895c	15&16
Hewlett Packard	Deskjet	895cxi	15&16
Hewlett Packard	Deskjet	920c	15&16
Hewlett Packard	Deskjet	930c	15&16
Hewlett Packard	Deskjet	932c	15&16
Hewlett Packard	Deskjet	934c	15&16
Hewlett Packard	Deskjet	935c	15&16
Hewlett Packard	Deskjet	940c	15&16
Hewlett Packard	Deskjet	950c	15&16
Hewlett Packard	Deskjet	952c	15&16
Hewlett Packard	Deskjet	955c	15&16
Hewlett Packard	Deskjet	957c	15&16
Hewlett Packard	Deskjet	960cse	15&16
Hewlett Packard	Deskjet	960cxi	15&16
Hewlett Packard	Deskjet	970cse	15&16
Hewlett Packard	Deskjet	970cxi	15&16
Hewlett Packard	Deskjet	980cxi	15&16
Hewlett Packard	Deskjet	990c	15&16
Hewlett Packard	Deskjet	990cxi	15&16
Hewlett Packard	Deskjet	995c	15&16
Hewlett Packard	Deskjet	1000	15&16
Hewlett Packard	Deskjet	1000c	15&16

Hewlett Packard	Deskjet	1000cse	15&16
Hewlett Packard	Deskjet	1000cxi	15&16
Hewlett Packard	Deskjet	1100c	15&16
Hewlett Packard	Deskjet	1100cse	15&16
Hewlett Packard	Deskjet	1100cxi	15&16
Hewlett Packard	Deskjet	1120c	15&16
Hewlett Packard	Deskjet	1120cse	15&16
Hewlett Packard	Deskjet	1220c	15&16
Hewlett Packard	Deskjet	1220cse	15&16
Hewlett Packard	Deskjet	1220c/ps	15&16
Hewlett Packard	Deskjet	1220cxi	15&16
Hewlett Packard	Deskjet	3810	15&16
Hewlett Packard	Deskjet	3816	15&16
Hewlett Packard	Deskjet	3820	15&16
Hewlett Packard	Deskjet	3822	15&16
Hewlett Packard	Deskjet	6122	15&16
Hewlett Packard	Deskjet	6127	15&16
Hewlett Packard	Deskjet	9300	15&16
Hewlett Packard	Digital Copier/printer	310	15&16
Hewlett Packard	Fax	1220	15&16
Hewlett Packard	Fax	1220xi	15&16
Hewlett Packard	Fax	1230	15&16
Hewlett Packard	Officejet	V30	15&16
Hewlett Packard	Officejet	R40	15&16
Hewlett Packard	Officejet	R45	15&16
Hewlett Packard	Officejet	T45	15&16
Hewlett Packard	Officejet	V40	15&16
Hewlett Packard	Officejet	V45	15&16
Hewlett Packard	Officejet	G55	15&16
Hewlett Packard	Officejet	G55xi	15&16
Hewlett Packard	Officejet	K60	15&16
Hewlett Packard	Officejet	R60	15&16
Hewlett Packard	Officejet	R65	15&16
Hewlett Packard	Officejet	T65	15&16
Hewlett Packard	Officejet	K80	15&16
Hewlett Packard	Officejet	R80	15&16
Hewlett Packard	Officejet	G85	15&16
Hewlett Packard	Officejet	G85xi	15&16
Hewlett Packard	Officejet	G95	15&16
Hewlett Packard	Officejet	1170	15&16
Hewlett Packard	Officejet	1175	15&16
Hewlett Packard	Officejet	5105	15&16
Hewlett Packard	Officejet	5110	15&16
Hewlett Packard	Officejet Pro	1150c	15&16

Hewlett Packard	Officejet Pro	1150cse	15&16
Hewlett Packard	Officejet Pro	1170c	15&16
Hewlett Packard	Officejet Pro	1170cse	15&16
Hewlett Packard	Officejet Pro	1175cxi	15&16
Hewlett Packard	Professional Series	825c	15&16
Hewlett Packard	Professional Series	930c	15&16
Hewlett Packard	Professional Series	932c	15&16
Hewlett Packard	Professional Series	935c	15&16
Hewlett Packard	Professional Series	950c	15&16
Hewlett Packard	Professional Series	952c	15&16
Hewlett Packard	Professional Series	955c	15&16
Hewlett Packard	Professional Series	960c	15&16
Hewlett Packard	Professional Series	970c	15&16
Hewlett Packard	Professional Series	990c	15&16
Hewlett Packard	Professional Series	995c	15&16
Hewlett Packard	Professional Series	1000c	15&16
Hewlett Packard	Professional Series	1120c	15&16
Hewlett Packard	Professional Series	1220c	15&16
Hewlett Packard	Professional Series	1600c	15&16
Hewlett Packard	Professional Series	3820	15&16
Hewlett Packard	Professional Series	6122	15&16
Hewlett Packard	PSC	Photo Printer	15&16
Hewlett Packard	PSC	500	15&16
Hewlett Packard	PSC	500si	15&16
Hewlett Packard	PSC	700	15&16
Hewlett Packard	PSC	750	15&16
Hewlett Packard	PSC	750xi	15&16
Hewlett Packard	PSC	950	15&16
Hewlett Packard	Photosmart	P1100	15&16
Hewlett Packard	Photosmart	P1100xi	15&16
Hewlett Packard	Photosmart	1115	15&16
Hewlett Packard	Photosmart	P1115	15&16
Hewlett Packard	Photosmart	1215	15&16
Hewlett Packard	Photosmart	1215vm	15&16
Hewlett Packard	Photosmart	P1215	15&16
Hewlett Packard	Photosmart	1218	15&16
Hewlett Packard	Photosmart	1218xi	15&16
Hewlett Packard	Photosmart	P1218	15&16
Hewlett Packard	Photosmart	1315	15&16
Hewlett Packard	Photosmart	P1315	15&16
Hewlett Packard	PSC	6127	15&16
Hewlett Packard	Deskjet	1280	15&16
Hewlett Packard	Deskjet	3745c	~

Hewlett Packard	Deskjet	5740	~
Hewlett Packard	Deskjet	6540	~
Hewlett Packard	Deskjet	6840	~
Hewlett Packard	Deskjet	6840DT	~
Hewlett Packard	Photosmart	325	~
Hewlett Packard	Photosmart	375	~
Hewlett Packard	Photosmart All-In-One	2610	~
Hewlett Packard	Photosmart All-In-One	2710	~
Hewlett Packard	Photosmart	8450 GP	~
Hewlett Packard	Photosmart	8150	~
Hewlett Packard	PSC	2353	~
Hewlett Packard	PSC	2355	~
Hewlett Packard	Officejet All-In-One	7310	~
Hewlett Packard	Officejet All-In-One	7410	~
Hewlett Packard	Deskjet	6620	~
Hewlett Packard	Deskjet	6520	~
Hewlett Packard	Officejet	6210	~
Hewlett Packard	Photosmart	8750	~
Hewlett Packard	Deskjet	9800	~
Hewlett Packard	Photosmart	2613	~
Hewlett Packard	Photosmart	8153	~
Hewlett Packard	Deskjet	5743	~
Hewlett Packard	PSC	2350	~
Hewlett Packard	PSC	1610	~
Hewlett Packard	Deskjet	5748	~
Hewlett Packard	Deskjet	6548	~
Hewlett Packard	Deskjet	5743	~
Hewlett Packard	Deskjet	6543	~
Hewlett Packard	Deskjet	1125c	15&16
Hewlett Packard	Officejet	7205	~
Hewlett Packard	Officejet	7210	~
Hewlett Packard	Officejet	7210v	~
Hewlett Packard	Officejet	7210xi	~
Hewlett Packard	Officejet	7213	~
Hewlett Packard	Officejet	7215	~
Hewlett Packard	Officejet	4212	4
Hewlett Packard	Officejet	4215	4
Hewlett Packard	Officejet	4255	4
Hewlett Packard	Officejet	4219	4
Hewlett Packard	Photosmart	8050	~
Hewlett Packard	Deskjet	9840	~
Hewlett Packard	PSC	1410	4
Hewlett Packard	Photosmart	385 photo	~
Hewlett Packard	Photosmart	335 photo	~

Hewlett Packard	Photosmart	P8750gp	~
Hewlett Packard	Deskjet Mobile	460	~
Hewlett Packard	Photosmart	320	~
Hewlett Packard	Photosmart	370	~
Hewlett Packard	Officejet	2575	~
Hewlett Packard	Deskjet	3940	4
Hewlett Packard	Deskjet	3930	4
Hewlett Packard	Deskjet	3920	4
Hewlett Packard	Deskjet	3940	4
Hewlett Packard	Deskjet	3930	4
Hewlett Packard	Deskjet	3920	4
Hewlett Packard	Portable Studio	422	~
Hewlett Packard	Portable Studio	428	~
Hewlett Packard	PSC	1510	~
Hewlett Packard	Officejet PFSC	9110	~
Hewlett Packard	Designjet	500	~
Hewlett Packard	Designjet	500ps	~
Hewlett Packard	Designjet	800	~
Hewlett Packard	Designjet	800ps	~
Hewlett Packard	Officejet PFSC	9120	~
Hewlett Packard	Officejet PFSC	9130	~
Hewlett Packard	Professional Series	2000c	~
Hewlett Packard	Professional Series	2500c	~
Hewlett Packard	cp	1700	~
Hewlett Packard	cp	1700d	~
Hewlett Packard	cp	1700ds	~
Hewlett Packard	cp	1700ps	~
Hewlett Packard	Designjet	Series	~
Hewlett Packard	Designjet	10ps	~
Hewlett Packard	Designjet	20ps	~
Hewlett Packard	Designjet	100	~
Hewlett Packard	Business Inkjet	1100	~
Hewlett Packard	Business Inkjet	1100d	~
Hewlett packard	Business Inkjet	1200	~
Hewlett packard	Business Inkjet	1200d	~
Hewlett packard	Business Inkjet	1200dn	~
Hewlett packard	Business Inkjet	1200dtn	~
Hewlett packard	Business Inkjet	2300n	~
Hewlett packard	Business Inkjet	3000dtn	~
Hewlett Packard	Business Inkjet	2200	~
Hewlett Packard	Business Inkjet	2200xi	~
Hewlett Packard	Business Inkjet	2200se	~
Hewlett Packard	Business Inkjet	2230	~
Hewlett Packard	Business Inkjet	2250	~

Hewlett Packard	Business Inkjet	2250tn	~
Hewlett Packard	Business Inkjet	2280	~
Hewlett Packard	Business Inkjet	2280tn	~
Hewlett Packard	Business Inkjet	2300	~
Hewlett Packard	Business Inkjet	2500	~
Hewlett Packard	Business Inkjet	2600	~
Hewlett Packard	Business Inkjet	2600dn	~
Hewlett Packard	Business Inkjet	2800	~
Hewlett Packard	Business Inkjet	3000	~
Hewlett Packard	Business Inkjet	3000n	~
Hewlett Packard	~	Series	~
Hewlett Packard	Deskjet	50ps	~
Hewlett Packard	Designjet	70	N/R
Hewlett Packard	Designjet	110+	N/R
Hewlett Packard	PSC	1402	4
Hewlett Packard	Photosmart	3210	~
Hewlett Packard	Photosmart	8250	~
Hewlett Packard	Officejet All in One FSC	5610	4
Hewlett Packard	Designjet	600	1
Hewlett Packard	Fax	925cxi	1 & 2
Hewlett Packard	Officejet	4105	4
Hewlett Packard	Officejet	5505	4
Hewlett Packard	Officejet	5605	4
Hewlett Packard	Officejet	5605z	4
Hewlett Packard	Officejet	5608	4
Hewlett Packard	Officejet	5610	4
Hewlett Packard	Officejet	5610v	4
Hewlett Packard	Officejet	5610xi	4
Hewlett Packard	Officejet	7218	~
Hewlett Packard	Officejet	725	1 & 2
Hewlett Packard	Officejet	7310	~
Hewlett Packard	Officejet	7310xi	~
Hewlett Packard	Officejet	7313	~
Hewlett Packard	Officejet	7408	~
Hewlett Packard	Officejet	6200	~
Hewlett Packard	Officejet	625	1 & 2
Hewlett Packard	Officejet	7410	~
Hewlett Packard	Officejet	7410xi	~
Hewlett Packard	Officejet	7413	~
Hewlett Packard	Officejet	9110	~
Hewlett Packard	Officejet	9120	~
Hewlett Packard	Officejet	9130	~
Hewlett Packard	Officejet	LX350	1

Hewlett Packard	Photosmart	1000	15 & 16
Hewlett Packard	Photosmart	2510	4
Hewlett Packard	Photosmart	2575v	~
Hewlett Packard	Photosmart	2575xi	~
Hewlett Packard	Photosmart	2610	~
Hewlett Packard	Photosmart	2710	~
Hewlett Packard	Photosmart	2713	~
Hewlett Packard	Photosmart	3100	~
Hewlett Packard	Photosmart	3200	~
Hewlett Packard	Photosmart	3300	~
Hewlett Packard	Photosmart	475	~
Hewlett Packard	Photosmart	7155	4
Hewlett Packard	Photosmart	7850	~
Hewlett Packard	Photosmart	7850v	~
Hewlett Packard	Photosmart	7850xi	~
Hewlett Packard	Photosmart	7853	~
Hewlett Packard	Photosmart	8050v	~
Hewlett Packard	Photosmart	8050xi	~
Hewlett Packard	Photosmart	8200	~
Hewlett Packard	Photosmart	8450	~
Hewlett Packard	Photosmart	8450v	~
Hewlett Packard	Photosmart	8450xi	~
Hewlett Packard	Photosmart	8453	~
Hewlett Packard	Photosmart	P1000	15 & 16
Hewlett Packard	Photosmart	P7150	4
Hewlett Packard	PSC	1110v	4
Hewlett Packard	PSC	1312	4
Hewlett Packard	PSC	1315xi	4
Hewlett Packard	PSC	1340	~
Hewlett Packard	PSC	1345	~
Hewlett Packard	PSC	1350v	4
Hewlett Packard	PSC	1350xi	4
Hewlett Packard	PSC	1358	4
Hewlett Packard	PSC	1400	4
Hewlett Packard	PSC	1610v	~
Hewlett Packard	PSC	1610xi	~
Hewlett Packard	PSC	1613	~
Hewlett Packard	PSC	2100	4
Hewlett Packard	PSC	2150	4
Hewlett Packard	PSC	2215	4
Hewlett Packard	PSC	2420	4
Hewlett Packard	PSC	2510	4
Hewlett Packard	PSC	2610	~
Hewlett Packard	PSC	370	~

Hewlett Packard	PSC	900	15 & 16
Hewlett Packard	Deskjet	200	1 & 2
Hewlett Packard	Deskjet	2000c	~
Hewlett Packard	Deskjet	200cci	1 & 2
Hewlett Packard	Deskjet	2500c	~
Hewlett Packard	Deskjet	330	1 & 2
Hewlett Packard	Deskjet	3300	4
Hewlett Packard	Deskjet	3620	4
Hewlett Packard	Deskjet	3645	4
Hewlett Packard	Deskjet	3647	4
Hewlett Packard	Deskjet	3650	4
Hewlett Packard	Deskjet	3651	4
Hewlett Packard	Deskjet	3847	4
Hewlett Packard	Deskjet	3910	4
Hewlett Packard	Deskjet	3915	4
Hewlett Packard	Deskjet	460c	~
Hewlett Packard	Deskjet	460cb	~
Hewlett Packard	Deskjet	460wbt	~
Hewlett Packard	Deskjet	5151	4
Hewlett Packard	Deskjet	5655	4
Hewlett Packard	Deskjet	5745	~
Hewlett Packard	Deskjet	5940	~
Hewlett Packard	Deskjet	6110	4
Hewlett Packard	Deskjet	6120	15 & 16
Hewlett Packard	Deskjet	615c	1 & 2
Hewlett Packard	Deskjet	6843	~
Hewlett Packard	Deskjet	6848	~
Hewlett Packard	Deskjet	691c	1 & 2
Hewlett Packard	Deskjet	7762	4
Hewlett Packard	Deskjet	816c	15 & 16
Hewlett Packard	Deskjet	825c	15 & 16
Hewlett Packard	Deskjet	9000	15 & 16
Hewlett Packard	Deskjet	916c	15 & 16
Hewlett Packard	Deskjet	959c	15 & 16
Hewlett Packard	Deskjet	Plus	1 & 2
Hewlett Packard	Deskwriter	670c	1 & 2
Hewlett Packard	Digital Copier	310	15 & 16
Hewlett Packard	Digital Copier	320	15 & 16

	Not Refillable
	Separate Instructions
	Checking For Updates
	NEW
	Cannot Refill Originals
	Ammendments

Printer Type	Series Type	Printer Models	Page No
Kodak	Picturemaker	1000	12
Kodak	Personal Picture Maker	2000	12
Kodak	Personal Picture Maker	100	12
Kodak	Personal Picture Maker	120	12
Kodak	Personal Picture Maker	PPM200	12
Kodak	Easyshare Dock	6000	N/R

	Not Refillable
	Separate Instructions
	Checking For Updates
	NEW
	Cannot Refill Originals
	Ammendments

Printer Type	Series Type	Printer Models	Page No
Lexmark	All in One	F4270	12
Lexmark	All in One	X63	12
Lexmark	All in One	X70	12
Lexmark	All in One	X73	12
Lexmark	All in One	X80	12
Lexmark	All in One	X83	12
Lexmark	All in One	X84	12
Lexmark	All in One	X85	12
Lexmark	All in One	X85 Pro	12
Lexmark	All in One	X4250	12
Lexmark	All in One	X4270	12
Lexmark	All in One	Z82	12
Lexmark	All in One	X125	12
Lexmark	All in One	X72	14
Lexmark	All in One	X74	14
Lexmark	All in One	X75	14
Lexmark	All in One	X1180	14
Lexmark	All in One	X1185	14

Lexmark	All in One	X2250	14
Lexmark	All in One	X2230	14
Lexmark	All in One	X5150	13
Lexmark	All in One	X5190 pro	13
Lexmark	All in One	X6150	13
Lexmark	All in One	X6170	13
Lexmark	All in One	X6190 pro	13
Lexmark	All in One	P3120	12
Lexmark	All in One	P3140	12
Lexmark	All in One	P3150	12
Lexmark	All in One	X2200	14
Lexmark	All in One	P4350	~
Lexmark	All in One	X3350	~
Lexmark	All in One	X1190	14
Lexmark	All in One	X3330	~
Lexmark	All in One	X5200	~
Lexmark	All in One	X5250	~
Lexmark	All in One	X5260	~
Lexmark	All in One	X5270	~
Lexmark	All in One	X7170	~
Lexmark	All in One	P6350	~
Lexmark	Colour Inkjet	1000	12
Lexmark	Colour Inkjet	1020	12
Lexmark	Colour Inkjet	1100	12
Lexmark	Colour Inkjet	2030	12
Lexmark	Colour Inkjet	2050	12
Lexmark	Colour Inkjet	2055	12
Lexmark	Colour Inkjet	3000	12
Lexmark	Colour Inkjet	4076	12
Lexmark	Colour Inkjet	2070	12
Lexmark	Colour Inkjet	3100	12
Lexmark	Colour Inkjet	3200	12

Lexmark	Colour Inkjet	5000	12
Lexmark	Colour Inkjet	5700	12
Lexmark	Colour Inkjet	5770	12
Lexmark	Colour Inkjet	7000	12
Lexmark	Colour Inkjet	7200	12
Lexmark	Colour Inkjet	7200v	12
Lexmark	Colour Inkjet	Z31	12
Lexmark	Colour Inkjet	Z11	12
Lexmark	Colour Inkjet	Z12	12
Lexmark	Colour Inkjet	Z22	12
Lexmark	Colour Inkjet	Z32	12
Lexmark	Colour Inkjet	Z42	12
Lexmark	Colour Inkjet	Z43	12
Lexmark	Colour Inkjet	Z44	12
Lexmark	Colour Inkjet	Z45	12
Lexmark	Colour Inkjet	Z45se	12
Lexmark	Colour Inkjet	Z51	12
Lexmark	Colour Inkjet	Z52	12
Lexmark	Colour Inkjet	Z53	12
Lexmark	Colour Inkjet	Z54	12
Lexmark	Colour Inkjet	Z54se	12
Lexmark	Colour Inkjet	Z23	14
Lexmark	Colour Inkjet	Z24	14
Lexmark	Colour Inkjet	Z25	14
Lexmark	Colour Inkjet	Z25L	14
Lexmark	Colour Inkjet	Z33	14
Lexmark	Colour Inkjet	Z34	14
Lexmark	Colour Inkjet	Z35	14
Lexmark	Colour Inkjet	I3	14
Lexmark	Colour Inkjet	A10	14
Lexmark	Colour Inkjet	Z513	14
Lexmark	Colour Inkjet	Z515	14
Lexmark	Colour Inkjet	Z600	14
Lexmark	Colour Inkjet	Z601	14
Lexmark	Colour Inkjet	Z604	14
Lexmark	Colour Inkjet	Z605	14
Lexmark	Colour Inkjet	Z612	14
Lexmark	Colour Inkjet	Z615	14
Lexmark	Colour Inkjet	X1100	14
Lexmark	Colour Inkjet	X1150	14
Lexmark	Colour Inkjet	X1160	14
Lexmark	Colour Inkjet	Z55	13
Lexmark	Colour Inkjet	Z55se	13
Lexmark	Colour Inkjet	Z65	13

Lexmark	Colour Inkjet	Z65n	13
Lexmark	Colour Inkjet	Z65p	13
Lexmark	Colour Inkjet	X5100	13
Lexmark	Colour Inkjet	X5130	13
Lexmark	Colour Inkjet	Z700	12
Lexmark	Colour Inkjet	Z703	12
Lexmark	Colour Inkjet	Z705	12
Lexmark	Colour Inkjet	Z706	12
Lexmark	Colour Inkjet	Z708	12
Lexmark	Colour Inkjet	Z715	12
Lexmark	Colour Inkjet	P700	12
Lexmark	Colour Inkjet	P704	12
Lexmark	Colour Inkjet	P706	12
Lexmark	Colour Inkjet	P707	12
Lexmark	Colour Inkjet	4070	5
Lexmark	Colour Inkjet	4079	8
Lexmark	Colour Inkjet	4126	14
Lexmark	Colour Inkjet	X1170	14
Lexmark	Colour Inkjet	Z517	14
Lexmark	Colour Inkjet	Z617	14
Lexmark	Colour Inkjet	P915	~
Lexmark	Colour Inkjet	P6250	~
Lexmark	Colour Inkjet	Z800	~
Lexmark	Colour Inkjet	Z815	~
Lexmark	Colour Inkjet	Z818	~
Lexmark	Colour Inkjet	Z810	~
Lexmark	Colour Inkjet	P450	~
Lexmark	Colour Inkjet	X1155	14
Lexmark	Colourjet	Z13	14
Lexmark	Execjet	II	12
Lexmark	Execjet	IIc	12
Lexmark	Jetprinter	X1130	14
Lexmark	Medley	4c	12

Lexmark	Medley	4x	12
Lexmark	Medley	4sx	12
Lexmark	Optracolor	45	12
Lexmark	Optracolor	40	12
Lexmark	Photo	P6200	~
Lexmark	Photo Inkjet	Z816	~
Lexmark	Photojet	P315	~
Lexmark	Winwriter	150c	12
Lexmark	Winwriter	100	12
Lexmark	All in One	X2350	~
Lexmark	Compact	Z735	~
Lexmark	All in One	P4330	~
Lexmark	Colour Inkjet	4072	~
Lexmark	Colour Inkjet	9000	12
Lexmark	Execjet	II 4076	12
Lexmark	Colour Inkjet	F4250	12
Lexmark	Colour Inkjet	J110	~
Lexmark	Colour Inkjet	P122	12
Lexmark	Colour Inkjet	P703	12
Lexmark	Colour Inkjet	P705	12
Lexmark	Colour Inkjet	P708	12
Lexmark	Colour Inkjet	X52	~
Lexmark	Colour Inkjet	X5210	~
Lexmark	Colour Inkjet	X6100	~
Lexmark	Colour Inkjet	X8350	~
Lexmark	Colour Inkjet	Z23e	14
Lexmark	Colour Inkjet	Z41	12
Lexmark	Colour Inkjet	X1110	14
Lexmark	Colour Inkjet	X1140	14
Lexmark	Colour Inkjet	X125 Pro	12
Lexmark	Colour Inkjet	X2240	14
Lexmark	Colour Inkjet	X2310	~
Lexmark	Colour Inkjet	X2330	~
Lexmark	Colour Inkjet	Z602	14
Lexmark	Colour Inkjet	Z603	14
Lexmark	Colour Inkjet	Z80	12
Lexmark	Colour Inkjet	Z812	~
Lexmark	Colour Inkjet	Z915	~
Lexmark	Colour Inkjet	P910	~

	Not Refillable
	Separate Instructions
	Checking For Updates
	NEW
	Cannot Refill Originals
	Ammendments

Printer Type	SeriesType	Printer No	Page No
Olivetti	~	JP- 50	23
Olivetti	~	JP- 70	23
Olivetti	~	JP- 90	23
Olivetti	~	JP- 150	17
Olivetti	~	JP- 170	17
Olivetti	~	JP- 190	17
Olivetti	~	JP- 192	17
Olivetti	~	JP- 250	17
Olivetti	~	JP- 270	17
Olivetti	~	JP- 350	17
Olivetti	~	JP- 360	17
Olivetti	~	JP- 370	17
Olivetti	~	JP- 450	17
Olivetti	~	JP- 470	17
Olivetti	~	JP- 790	17
Olivetti	~	JP- 792	17
Olivetti	~	JP- 795	17
Olivetti	~	JP- 883	17
Olivetti	~	JP-192sc	17
Olivetti	~	JP-150w	17
Olivetti	~	JP-150ws	17
Olivetti	~	JP-170c	17
Olivetti	~	JP-170s	17
Olivetti	~	JP-350s	17
Olivetti	~	JP-350ws	17
Olivetti	~	OFX-100	17

Olivetti	~	OFX-520	17
Olivetti	~	OFX-520p	17
Olivetti	~	OFX-525	17
Olivetti	~	OFX-540	17
Olivetti	~	OFX-550	17
Olivetti	~	OFX-560	17
Olivetti	~	OFX-570	17
Olivetti	~	OFX-580	17
Olivetti	~	OFX-800	17
Olivetti	~	OFX-2100	17
Olivetti	~	OFX-3100	17
Olivetti	~	OFX-3200	17
Olivetti	~	OFX-120	17
Olivetti	~	JP- 90+	23
Olivetti	ArtJet	10	17
Olivetti	ArtJet	12	17
Olivetti	ArtJet	20	17
Olivetti	Artjet	22	17
Olivetti	Copylab	200	17
Olivetti	Copylab	250	17
Olivetti	Fax	OFX-140	17
Olivetti	Fax	OFX-180	17
Olivetti	Fax	OFX-575	17
Olivetti	Faxlab	600	17
Olivetti	Faxlab	200p	17
Olivetti	Faxlab	200	17
Olivetti	Faxlab	210	17
Olivetti	Faxlab	250p	17
Olivetti	Faxlab	260	17
Olivetti	Faxlab	210p	17
Olivetti	Faxlab	260p	17
Olivetti	Faxlab	250	17
Olivetti	Faxlab	220	23
Olivetti	Faxlab	270	23
Olivetti	Faxlab	300	23
Olivetti	Faxlab	310	23
Olivetti	Faxlab	350	23
Olivetti	Faxlab	360	23
Olivetti	Faxlab	450	23
Olivetti	Faxlab	100	23
Olivetti	Faxlab	115	23

Olivetti	Faxlab	275	23
Olivetti	Faxlab	95	23
Olivetti	Faxlab	120	23
Olivetti	Jetlab	500	17
Olivetti	Jetlab	600	17
Olivetti	Jetlab	600a	17
Olivetti	Jetlab	400	23
Olivetti	Jetlab	490	23
Olivetti	Jetwriter	900	23
Olivetti	Jetwriter	910	23
Olivetti	Job Jet	P200	15 & 16
Olivetti	Linkfax	500	17
Olivetti	Linkfax	1000	17
Olivetti	Linkfax	1100	17
Olivetti	Linkfax	1200	17
Olivetti	Linkfax	1900	17
Olivetti	Linkfax	2100	17
Olivetti	Linkfax	2200	17
Olivetti	Linkfax	3100	17
Olivetti	Linkfax	3200	17
Olivetti	Linkfax	OFX-500	17
Olivetti	Linkfax	OFX-1000	17
Olivetti	Linkfax	OFX-1100	17
Olivetti	Linkfax	OFX-1200	17
Olivetti	Linkfax	OFX-1900	17
Olivetti	Linkfax	OFX-2200	17
Olivetti	Nomadjet	100	23
Olivetti	Nomadjet	200	23
Olivetti	OFX	575	17
Olivetti	Studio Jet	300	17
Olivetti	Studio Jet	910	23
Olivetti	Faxlab	M100	17
Olivetti	Faxlab	S100	17
Olivetti	Faxlab	S120	17
Olivetti	~	JP-883	~

	Not Refillable
	Separate Instructions
	Checking For Updates
	NEW
	Cannot Refill Originals
	Ammendments

Printer	Printer Type	Model No	Page No
Addmaster	~	IJ-2040	~
Addmaster	Marchant	2001	~
Addressease	ELP	~	~
Addressease	Envelope Toaster	~	~
Advance	Hi-Tech Maillet	~	1
AGFA	Microfilm Camera	~	1
Aittell	Inkfax	~	1
Printer	Printer Type	Model No	Page No
Business System	Intl Lasersoft I	~	~
BDT	Ergoprint	310	1
Bryce Office System	BOS 10 Add	~	1
Printer	Printer Type	Model No	Page No
Calcomp	Techjet Design	5436	9
Calcomp	Techjet Personal	~	9
Compaq	~	IJ-200	12
Compaq	~	IJ-300	12
Compaq	~	IJ-600	12

Compaq	~	IJ-700	12
Compaq	~	IJ-750	12
Compaq	~	IJ-900	12
Compaq	~	IJ-1000	12
Compaq	~	IJ-1200	12
Compaq	Pagemaster	201	12
Compaq	All in One	A1000	12
Compaq	~	A900	12
Compaq	Three in one	C3-1000	12
Compaq	Multifunction	A1500	12
Compaq	~	1400p	12
Compaq	~	IJ 650	14
Compaq	~	IJ -1400p	12
Compaq	~	A3000	12
Compaq	~	A4000	12
Casio	~	PJ-140L	1
Citizen	Project	~	1
Citizen	Project II	~	1
Colossal	Graphic Colossalijet FB	~	1
Commodore	MPS	1270	1
Compuprint	Pagemaster	200	1
Compuprint	Pagemaster	201	1
Chinon	~	K-116	~
Chinon	~	K-128	~
Comtech	Jetwriter	200	~
Conterm	Deskjet	200	~
Costar	Address Express	~	~
Printer	Printer Type	Model No	Page No
Data General	~	2698	~
Data Sec Corp	~	DSP-225	~
Diconix	~	15	~
Diconix	~	150 Plus	~
Diconix	~	180si	~
Diconix	~	300	~
Diconix	~	300w	~
Diconix	~	M150 Plus	~
Data Tech	DirectJet	100 Add	1

Data Tech	DP	1186 Add System	1
Data Tech	Scriptomatic	BOS-10K Add	1
Data Tech	Scriptomatic	BOS-10K E Add	1
DEC	Decmulti Jet	1000	1
DEC	Decmulti Jet	2000	1
Dex Business System	DEX	530	1
Printer	Printer Type	Model No	Page No
Enter Computer	Novajet	~	1
Enter Computer	Novajet	II	1
ENC	Electronics	EJ-105	~
Printer	Printer Type	Model No	Page No
Fujisu	Breeze	100	1
Fujisu	Breeze	100 Plus	1
Fujisu	Breeze	200	1
Fujisu	Breeze	DEX 530	1
Facit	~	J1200	~
Facit	~	J1250	~
Printer	Printer Type	Model No	Page No
General Comp	Corp Writermove	~	~
GSD systems	Inkjet	5224	~

Printer	Printer Type	Model No	Page No
Honeywell	Bull Pagemaster	200	1
Honeywell	Bull Pagemaster	201	1
Printer	Printer Type	Model No	Page No
IJ Technologyies	New Horizons	~	1
Integrex	Betajet	~	1
Integrex	Colourjet 2	~	1
ITT	Opus	3735	1
ITT	Opus	3740	1
ITT	Opus	3745	1
IBM	~	4070 IJ Model 1	9
IBM	~	4070 IJ Model 2	9
Printer	Printer Type	Model No	Page No
Konica	FAX	9410	9
Printer	Printer Type	Model No	Page No
Lasermaster	Displaymaker	~	1

Printer	Printer Type	Model No	Page No
Miltope	Corp Jet	150	~
Mannesmann Tally	~	T7018	1
Mannesmann Tally	~	T7040	1
Printer	Printer Type	Model No	Page No
NEC Jetmate	~	400	1
NEC Jetmate	~	800	1
North Atlantic	Deskjet	Plus T	1
North Atlantic	Deskjet	T	1
Newgen Systems	Vista Printing	~	1
Nixdorf	~	MD-16	~
Nixdorf	~	MD-22	~
Northern Telecom	Displayjet	~	~
Printer	Printer Type	Model No	Page No
Oki	Okijet	OJ2010	12
Oki	Okijet	OJ300	12
Oki	Okijet	300	12
Oki	Okijet	300c	12
Oki	Okijet	2010	12
Oki	Microlinejet	300 Color	12
Oki	Okijet	2020	20
Oki	~	2500	20
Oki	Okijet	2025	20
Oki	Fax	740MF	12

Olympia	Colour Star		1
Olympia	~	OF-710	1
Olympia	~	OF-720	1
Olympia	Quietstar	4	1
Printer	Printer Type	Model No	Page No
Pitney Bowes	~	W800 Addressright	1
Pitney Bowes	~	W880 Addressright	1
Pitney Bowes	~	9100	1
Philips	Inkjet fax	IPF 131	~
Philips	Ansaphone Inkjet Fax	IPF 174	~
Philips	Inkjet fax	IPF 325	~
Philips	MF-JET	495	14
Philips	MF-JET	450	14
Philips	MF-JET	500	14
Philips	Faxjet	375	~
Printer	Printer Type	Model No	Page No
Royal	~	CJP-450	1
Rena	~	DA-600	1
Printer	Printer Type	Model No	Page No
Sagem	~	Safa Jet	1
Scan	Code Optimizer	~	1
Seikosha	Speed Jet	200	1

Seikosha	Speed Jet	300	~
Siemens		4812-10	1
Siemens	Fax	540	1
Siemens	Fax	550	1
Smith Corona	Coronajet	200J	1
Stielow	Address Printer	5923	1
Stielow	Address Printer	5980	1
Star Micronics Starjet	~	SJ-48	9
Star Micronics Starjet	~	SJ-48 Plus	9
Printer	Printer Type	Model No	Page No
Triumph Adler		JPR-630	1
Triumph Adler		JPR-635	1
Triumph Adler		JPR-7825	1
Triumph Adler		JPR-7825WS	1
Triumph Adler		JPR-7840	1
Triumph Adler		JPR-7845	1
Triumph Adler		JPR-7850	1
Triumph Adler		JPR-7850WS	1
Triumph Adler		JPR-7860	1
Trace CDP		5300	9
Tidemark Corp	Address Express	~	~
Printer	Printer Type	Model No	Page No
Radio Shack	~	JP-250	9
Ricoh	~	Fax-800	9

Printer	Printer Type	Model No	Page No
Utax Starwriter		80	9
Printer	Printer Type	Model No	Page No
Westrex		WP-1000	~

	Not Refillable
	Separate Instructions
	Checking For Updates
	NEW
	Cannot Refill Originals
	Ammendments

Printer Type	Series Type	Model No	Page No
Panasonic Panafax	FAX	KX-PJ250	1
Panasonic Panafax	FAX	PD-2300	1
Panasonic Panafax	FAX	PD-4200	1
Panasonic Panafax	FAX	PX-350	1
Panasonic Panafax	FAX	PX-360	1
Panasonic Panafax	FAX	UF-305	1
Panasonic Panafax	FAX	UF-300	1
Panasonic Panafax	FAX	UF-310	1
Panasonic Panafax	FAX	UF-311	1
Panasonic Panafax	FAX	UF-312	1
Panasonic Panafax	FAX	UF-315	1
Panasonic Panafax	FAX	UF-321	1
Panasonic Panafax	FAX	UF-322	1
Panasonic Panafax	FAX	UF-342	10
Panasonic Panafax	FAX	UF-344	10
Panasonic Panafax	FAX	KX-F1600	10
Panasonic Panafax	FAX	KX-F1650	10
Panasonic Panafax	Winwriter	150c	12

	Not Refillable
	Separate Instructions
	Checking For Updates
	NEW
	Cannot Refill Originals
	Ammendments

Printer Ref	Model	Series	Page Number
Philips	Inkjet fax	IPF 131	~
Philips	Ansaphone Inkjet Fax	IPF 174	~
Philips	Inkjet fax	IPF 325	~
Philips	MF-JET	495	14
Philips	MF-JET	450	14
Philips	MF-JET	500	14
Philips	Faxjet	375	~
Philips	iJet	Primo	~
Philips	iJet	Voice	~
Philips	Inkjet fax	IPF 146	~
Philips	Inkjet fax	IPF176	~

	Not Refillable
	Separate Instructions
	Checking For Updates
	NEW
	Cannot Refill Originals
	Ammendments

Printer Type	Series Type	Model No	Page No
Samsung	Myjet	~	12
Samsung	Myjet Color	900	12
Samsung	Myjet Color	960	12
Samsung	Myjet Color	965	12
Samsung	Myjet Color	980	12
Samsung	Myjet Color	1010	12
Samsung	Myjet Color	1060	12
Samsung	Myjet Color	1065	12
Samsung	Myjet Color	1210	12
Samsung	Myjet Color	1310	12
Samsung	Myjet Win	~	12
Samsung	Myjet Win +	~	12
Samsung	Myjet Win	630	12
Samsung	Myjet Win	635	12
Samsung	Myjet Win	640	12
Samsung	Myjet Win	650	12
Samsung	Myjet Win	655	12
Samsung	Myjet Win	660	12
Samsung	Myjet Win	760	12
Samsung	Myjet Win	765	12
Samsung	Myjet Colour	II	12
Samsung	Myjet Colour	630	12

Samsung	Myjet Colour	640	12
Samsung	Myjet Colour	650	12
Samsung	Myjet Colour	655	12
Samsung	Myjet Colour	660	12
Samsung	Myjet Colour	760	12
Samsung	Myjet Colour	765	12
Samsung	Myjet Colour	805	12
Samsung	Myjet Colour	850	12
Samsung	Myjet Colour	860	12
Samsung	Myjet Colour	900	12
Samsung	Myjet Colour	960	12
Samsung	Myjet Colour	965	12
Samsung	Myjet Colour	980	12
Samsung	Myjet Colour	1000	12
Samsung	Myjet Colour	7065	12
Samsung	Myjet Colour	1100	12
Samsung	Myjet Colour	1210	12
Samsung	Myjet Colour	1300	12
Samsung	Myjet Colour	1310	12
Samsung	Myjet Colour	1500	12
Samsung	Myjet Colour	1600	12
Samsung	~	EX-1000	12
Samsung	~	CF-430	12
Samsung	~	CF-3000	12
Samsung	~	CF-3100	12
Samsung	~	CF-3200	12
Samsung	~	CF-4000	12
Samsung	~	CF-4100	12
Samsung	~	CF-4200	12
Samsung	~	CF-4550	12
Samsung	~	CF-4700	12
Samsung	~	CF-4750	12
Samsung	~	FX-4000	12
Samsung	~	FX-4100	12
Samsung	~	FX-4105	12
Samsung	~	FX-4200	12
Samsung	~	FX-4205	12
Samsung	~	FX-4225	12
Samsung	~	MJ-63	12
Samsung	~	MJ-630	12
Samsung	~	MJ-635	12
Samsung	~	MJ-640	12
Samsung	~	MJ-4500C	12
Samsung	~	MSYS-	12

		4700	
Samsung	~	MSYS-4800	12
Samsung	~	MJC-500	12
Samsung	~	MJC-510	12
Samsung	~	MJC-520	12
Samsung	~	MJC-605	12
Samsung	~	MJC-640	12
Samsung	~	MJC-650	12
Samsung		MJC-655	12
Samsung	~	MJC-660	12
Samsung	~	MJC-665	12
Samsung	~	MJC-760	12
Samsung	~	MJC-765	12
Samsung	~	MJC-805	12
Samsung	~	MJC-850	12
Samsung	~	MJC-860	12
Samsung	~	MJC-900	12
Samsung	~	MJC-902	12
Samsung	~	MJC-930	12
Samsung	~	MJC-935	12
Samsung	~	MJC-940	12
Samsung	~	MJC-960	12
Samsung	~	MJC-970	12
Samsung	~	MJC-980	12
Samsung	~	MJC-985	12
Samsung	~	MJC-1000	12
Samsung	~	MJC-1010	12
Samsung	~	MJC-1015	12
Samsung	~	MJC-1030	12
Samsung	~	MJC-1040	12
Samsung	~	MJC-1060	12
Samsung	~	MJC-1065	12
Samsung	~	MJC-1100	12
Samsung	~	MJC-1115	12
Samsung	~	MJC-1130	12
Samsung	~	MJC-1210	12
Samsung	~	MJC-1215	12
Samsung	~	MJC-1250	12
Samsung	~	MJC-1300	12
Samsung	~	MJC-1310	12
Samsung	~	MJC-1315	12
Samsung	~	MJC-1500	12
Samsung	~	MJC-1600	12

Samsung	~	MJC-2100	12
Samsung	~	MJC-2200	12
Samsung	~	MJC-2300	12
Samsung	~	MJC-2400	12
Samsung	~	MJC-2500	12
Samsung	~	MJC-3000	12
Samsung	~	MJC-3100	12
Samsung	~	MJC3300P	12
Samsung	~	MJC-3400	12
Samsung	~	SF-300	12
Samsung	FAX	SF-350	12
Samsung	~	SF-430	12
Samsung	~	SF-3000	12
Samsung	~	SF-3100	12
Samsung	FAX	SF-3100p	12
Samsung	~	SF-3150	12
Samsung	FAX	SF3200	12
Samsung	~	SF-4000	12
Samsung	~	SF-4020	12
Samsung	~	SF-4100	12
Samsung	~	SF-4120	12
Samsung	~	SF-4200	12
Samsung	~	SF-4220	12
Samsung	FAX	SF-4300	12
Samsung	~	SF-4500	12
Samsung	~	SF-4500c	12
Samsung		SF-4550	12
Samsung	~	SF-4700	12
Samsung	~	SF-4750	12
Samsung	~	SCX-1000	12
Samsung	~	SCX-1020	12
Samsung	~	SCX-1050	12
Samsung	~	SCX-1100	12
Samsung	~	SCX-1150	12
Samsung	~	Smartjet	12
Samsung	FAX	SF-330	~
Samsung	FAX	SF-333ip	~
Samsung	FAX	SF-335st	~
Samsung	FAX	SF-345t	~
Samsung	FAX	SF-340	~
Samsung	FAX	SF-3000	12
Samsung	FAX	SF-3050	12
Samsung	FAX	SF331p	~

	Not Refillable
	Separate Instructions
	Checking For Updates
	NEW
	Cannot Refill Originals
	Ammendments

Printer Type	Printer Model	Series	Page Number
Sharpe	Docuprint	AJ-1100	21
Sharpe	Docuprint	AJ-6010	21
Sharpe	Docuprint	AJ-1805	21
Sharpe	Docuprint	AJ-2200	21
Sharpe	~	FO-1700	1
Sharpe	~	FO-3700	1
Sharp	~	UX-700	14
Sharp	~	UX-B700	14
Sharpe	~	UX-1200	1
Sharpe	~	UX-1500	1

	Not Refillable
	Separate Instructions
	Checking For Updates
	NEW
	Cannot Refill Originals
	Ammendments

Xerox	Multifunction	M-900	21
Xerox	Multifunction	M-940	21
Xerox	Multifunction	M-950	21
Xerox	DocuPrint Fax Center	DFC-155	17
Xerox	DocuPrint Fax Center	DFC-155c	17
Xerox	DocuPrint Fax Center	DFC-165c	17
Xerox	DocuPrint Fax Center	DFC-167c	17
Xerox	DocuPrint Fax Center	XJ8c	12
Xerox	DocuPrint Fax Center	M760	21
Xerox	Homecentre	XJ-2110	18
Xerox	DocuPrint Fax Center	WC470CX	12
Xerox	DocuPrint Fax Center	WC480CX	12
Xerox	DocuPrint Fax Center	WC490CX	12
Xerox	DocuPrint Fax Center	170	12
Xerox	DocuPrint Fax Center	190	12
Xerox	Homecentre	~	20